



WHAT'S IN THE BOX:

- A. Swing/support bracket
- B. Hood retaining clamp
- C. Upright support lever
- D. Upright support bar
- E. Hood support bar



- Thread the hood support clamp through the slots in the hood support bar bracket.
 Fig. 1
- Insert the upright support bar through the hood support bar and tighten with the lever lock.

Fig. 2

- Insert the upright support bar into the long slot of the swing/support bracket. Ensure the notched end of the upright support is engaged into the swing/support bracket.
 Fig. 3
- Attach the swing support bracket to the lathe bed by removing the heavy round key positioned under the lathe bed.
- Attach the hood with the hood retaining clamp.

Fig. 4

 Attach the hose to the dust hood with a standard hose clamp.
(Hood, hose and clamp not included.)







